840*148,5 mm

BACK → COVER

BACK

COVER

THE G-LAB

www.the-g-lab.tech

LE TRI FACILE

RECYCLE IN FRANCE

The G-LAB KEYZ CARBON PRO ©2026
Made in China
Distributed by :
AXS - 1 Rue de la Garenne ZI Le Vert Galant
95310 SAINT OUEN L'AUMONE - France

EU DECLARATION OF CONFORMITY

AXS declares under its sole responsibility as manufacturer that the product below :
Rainbow backlit mechanical gaming keyboard
The G-LAB KEYZ-CARBON-PRO/FR - EAN 3760162056600

Conforms to the following essential requirements and standards:

EU Directives	Conforms to
2014/53/EU – RED	EN 62368-1:2014+A11:2017 EN 62479:2010 EN 55032:2015+A11:2020 EN 55035:2017+A11:2020 EN 301 489-1 V2.2.3 EN 301 489-17 V3.2.4 EN 300 328 V2.2.2
2011/65/UE - RoHS with amendement 2015/863/UE	EN IEC 63000: 2018

Signed at SAINT OUEN L'AUMONE, the 10 july 2026
By Stefan Riesser
President AXS

SAFETY INSTRUCTIONS

Disconnect the product before cleaning. Use a dry, soft cloth. Do not use liquid or aerosol cleaners.

If the product emits unusual odor, heat, smoke, or shows signs of malfunction, disconnect it immediately and contact customer support.

If liquid or foreign objects enter the product, switch it off, unplug it, and remove the substance if possible.

Do not open, disassemble, or modify the product. Repairs must be carried out by qualified personnel only. Unauthorized modifications void the warranty.

BATTERY AND POWER SAFETY (if applicable)

General

Safety instructions for rechargeable batteries and cells (if applicable)

- Keep out of reach of children. If swallowed, seek medical attention immediately.
- Do not use a damaged or leaking battery.
- Do not short-circuit the terminals.
- Do not crush, puncture, disassemble, cut, or expose to fire or a hot oven.
- Disposing of a battery or rechargeable battery in fire or a hot oven, or mechanically crushing or cutting it, may result in an explosion.
- Extremely high or low temperatures to which batteries or rechargeable batteries may be exposed during use, storage, or transportation may present a hazard (see informations).
- Leaving a battery or rechargeable battery in an extremely high-temperature environment may result in an explosion or leakage of flammable liquid or gas.
- Subjecting a battery or rechargeable battery to extremely low air pressure may result in an explosion or leakage of flammable liquid or gas.
- Do not dispose of with household waste.

Non-rechargeable batteries (if applicable)

- Do not attempt to recharge non-rechargeable batteries.
- Insert batteries respecting polarity (+/-).
- Remove batteries if the product will not be used for a long period.

Rechargeable battery (if applicable)

- Use only the battery supplied or specified by the manufacturer.
- Do not replace the battery yourself unless explicitly stated.

- Incorrect replacement may cause explosion or fire.
- Do not expose the product or battery to excessive heat (sunlight, fire, etc.).
- Do not expose the product to extreme temperatures.
- Use, storage and transport must remain within specified temperature limits.

Charging (if applicable)

- Use only the supplied or approved charging system.

WARRANTY

This product is covered by a 2-year limited warranty from the date of purchase against manufacturing defects.

The warranty does not cover:

- Misuse or improper use.
- Mechanical or electrical damage.
- Unauthorized repair or modification.
- Normal wear and consumables (including batteries).

Proof of purchase is required. Warranty valid only in the country of purchase.

AXS reserves the right to repair or replace the product.

Statutory rights under applicable national law are not affected.

ENVIRONMENT

Product (WEEE)

Directive 2012/19/EU
This product must not be disposed of with household waste. It must be collected separately for recycling.

Batteries

Regulation (UE) 2023/1542
Batteries must be disposed of at designated collection points.

Packaging

Dispose of packaging according to local recycling regulations.

The G-LAB KEYZ CARBON PRO ©2026
Made in China
Distribué par :
AXS - 1 Rue de la Garenne ZI Le Vert Galant
95310 SAINT OUEN L'AUMONE - France

DÉCLARATION DE CONFORMITÉ UE

AXS déclare sous sa seule responsabilité en tant que fabricant que le produit ci-dessous :
Clavier mécanique gaming rétroéclairé rainbow
The G-LAB KEYZ-CARBON-PRO/FR - EAN 3760162056600

Est conforme aux exigences et normes essentielles suivantes :

Directives UE	Conforme suivant
2014/53/EU – RED	EN 62368-1:2014+A11:2017 EN 62479:2010 EN 55032:2015+A11:2020 EN 55035:2017+A11:2020 EN 301 489-1 V2.2.3 EN 301 489-17 V3.2.4 EN 300 328 V2.2.2
2011/65/UE - RoHS avec amendement 2015/863/UE	EN IEC 63000: 2018

Fait à SAINT OUEN L'AUMONE, le 10 juillet 2026
Par Stefan Riesser
Président AXS

CONSIGNES DE SÉCURITÉ

Débranchez le produit avant nettoyage. Utilisez un chiffon doux et sec. N'utilisez pas de produits liquides ou aérosols.

En cas d'odeur anormale, de surchauffe, de fumée ou de dysfonctionnement, débranchez immédiatement le produit et contactez le service après-vente.

Si un liquide ou un corps étranger pénètre dans le produit, éteignez-le, débranchez-le et retirez-le si possible.

Ne démontez pas et ne modifiez pas le produit. Les réparations doivent être effectuées par un professionnel qualifié. Toute modification non autorisée annule la garantie.

SÉCURITÉ DES BATTERIES ET DE L'ALIMENTATION (si concerné)

Général

Consignes de sécurité relatives aux piles et batteries rechargeables (si concerné)

- Tenir hors de portée des enfants. En cas d'ingestion, consulter immédiatement un médecin ;
- Ne pas utiliser de batterie endommagée ou présentant une fuite ;
- Ne pas court-circuiter les bornes ;
- Ne pas écraser, percer, démonter, couper ni exposer au feu ou à un four chaud ;
- Jeter une pile ou une batterie rechargeable au feu ou dans un four chaud, l'écraser mécaniquement ou la couper peut provoquer une explosion ;
- Des températures extrêmement basses ou élevées auxquelles les piles ou batteries rechargeables peuvent être soumises pendant l'utilisation, le stockage ou le transport peuvent présenter un danger (cf. tableau) ;
- Laisser une pile ou une batterie rechargeable dans un environnement à température extrêmement élevée peut provoquer une explosion ou une fuite de liquide ou de gaz inflammables ;
- Soumettre une pile ou une batterie rechargeable à une pression atmosphérique extrêmement basse peut provoquer une explosion ou une fuite de liquide ou de gaz inflammables ;
- Ne pas jeter avec les déchets ménagers.

Batterie non rechargeable (si concerné)

- Ne pas tenter de recharger des piles non rechargeables ;
- Respecter la polarité (+/-) ;
- Retirer les piles en cas de non-utilisation prolongée.

Batterie rechargeable (si concerné)

- Utiliser uniquement la batterie fournie ou recommandée ;
- Ne pas remplacer la batterie soi-même sauf indication explicite ;
- Un remplacement incorrect peut entraîner un risque d'explosion ou d'incendie ;
- Ne pas exposer à une chaleur excessive (soleil, feu, etc.) ;
- Ne pas exposer à des températures extrêmes. ;
- Respecter les conditions d'utilisation, stockage et transport spécifiées.

Recharge (si concerné)

- Utiliser uniquement le système de charge fourni ou approuvé.

GARANTIE

Garantie de 2 ans à compter de la date d'achat contre les défauts de fabrication.

Non couvert :

- Mauvaise utilisation ;
- Dommages électriques ou mécaniques ;
- Réparations non autorisées ;
- Usure normale et consommables (dont batteries).

Facture obligatoire. Garantie valable dans le pays d'achat.

AXS se réserve le droit de réparer ou remplacer le produit.

Les droits légaux applicables restent en vigueur.

ENVIRONNEMENT

Produit (DEEE)

Directive 2012/19/UE
Ne pas jeter avec les déchets ménagers.
Collecte séparée obligatoire.

Batteries

Règlement (UE) 2023/1542
À déposer dans des points de collecte dédiés.

Emballage

À trier selon les règles locales

KEYZ CARBON PRO

INSTRUCTION MANUAL
MANUEL D'UTILISATION
MANUAL DEL USUARIO
MANUALE D'USO
HANDBUCH
GEBRUIKERSHANDLEIDING



RAINBOW GAMING
MECHANICAL KEYBOARD

THE G-LAB

WRIST REST / REPOSE-POIGNET / APOYAMUÑECAS / POGGIAPOLSI / HANDGELENKSTÜTZE / POLSSTEUN



USB PLUG & PLAY



Does not require any driver, is automatically recognized by your system.
Ne nécessite aucun driver, est reconnu automatiquement par votre système.
No requiere ningun controlador, es reconocido automáticamente por su sistema.
Non richiede driver e viene riconosciuto automaticamente dal sistema.
Benötigt keinen Treiber, wird automatisch von Ihrem System erkannt.
Vereist geen stuurprogramma en wordt automatisch herkend door je system.

SHORTCUTS / RACCOURCIS CLAVIER / ATAJOS DE TECLADO SCORCIATOIE DA TASTIERA / TASTENKOMBINATIONEN / TOETSENBORDCOMBINATIES

Fn + Windows: Windows lock mode / Vérouille la touche Windows / Modo de bloqueo de Windows / Modalità Windows-lock / Windows-Lock-Modus / Windows-vergrendelingsmodus

Fn + Z: ZQSD to Arrows switch / Commutateur ZQSD vers Flèches / Cambia de ZQSD a flechas / Commutazione da ZQSD a Frecce / ZQSD-zu-Pfeil-Schalter / ZQSD naar pijlen schakelaar

Fn + F1	Fn + F5 ■	Fn + F9 ✉
Fn + F2 🔉−	Fn + F6 ⏮	Fn + F10
Fn + F3 🔊+	Fn + F7 ⏯	Fn + F11
Fn + F4 🔇	Fn + F8 ⏭	Fn + F12



Previous track / Piste précédente / Pista anterior / Brano precedente / Vorheriger Titel / Vorige nummer

Play/Pause / Lecture/Pause / Reproducir/Pausa / Riproduzione/Pausa / Wiedergabe/Pause / Afspelen/Pauzeren

Next track / Piste suivante / Siguiente pista / Brano successivo / Nächster Titel / Volgend nummer

Fn + Backlight mode: Switch backlight mode (17 kinds) / Changement de mode de rétroéclairage (17 sortes) / Cambio del modo de retroiluminación (17 tipos) / Modalità di retroilluminazione (17 tipi) / Wechsel des Hintergrundbeleuchtungsmodus (17 Varianten) / Achtergrondverlichting wijzigen (17 soorten)

Fn + Backlight brightness +: Backlight brightness + / Augmenter la luminosité du rétroéclairage de fond / Brillo de la retroiluminación + / Luminosità della retroilluminazione + / Helligkeit der Hintergrundbeleuchtung + / Helderheid achtergrondverlichting +

Fn + Backlight brightness -: Backlight brightness - / Diminuer la luminosité du rétroéclairage de fond / Brillo de la retroiluminación - / Luminosità della retroilluminazione - / Helligkeit der Hintergrundbeleuchtung - / Helderheid achtergrondverlichting -

Fn + Backlight speed effect -: Backlight speed effect - / Diminuer la vitesse de l'effet du rétroéclairage de fond / Efecto de velocidad de retroiluminación - / Effetto velocità della retroilluminazione - / Geschwindigkeitseffekt der Hintergrundbeleuchtung - / Snelheidseffect achtergrondverlichting -

Fn + Backlight speed effect +: Backlight speed effect + / Augmenter la vitesse de l'effet du rétroéclairage de fond / Efecto de velocidad de retroiluminación + / Effetto velocità della retroilluminazione + / Geschwindigkeitseffekt der Hintergrundbeleuchtung + / Snelheidseffect achtergrondverlichting +

Fn + Arrêt: On/Off lights / Allumage et extinction du rétroéclairage / Encender y apagar la retroiluminación / Accensione e spegnimento della retroilluminazione / Ein- und Ausschalten der Hintergrundbeleuchtung / De achtergrondverlichting in- en uitschakelen

Fn + Echap: Push during 5 seconds for reset all lights and effects / Appuyer pendant 5 secondes pour réinitialiser tous les lumières et effets / Pulsar durante 5 segundos para resetear todas las luces y efectos / Premere per 5 secondi per resettare tutte le luci e gli effetti / 5 Sekunden lang drücken, um alle Lichter und Effekte zurückzusetzen / Druk gedurende 5 seconden om alle lichten en effecten te resetten

SCROLL WHEEL / MOLETTE / RUEDA DE DESPLAZAMIENTO / ROTELLINA / SCROLLRADS / SCROLLWIELTJE

(press): Long press for 5 seconds to toggle between Volume Mode and Light mode / Appuyez pendant 5 secondes pour basculer entre le mode Volume et le mode Éclairage / Pulse durante 5 segundos para alternar entre el modo de volumen y el modo de luz / Premere per 5 secondi per passare dalla modalità Volume alla modalità Luce / Halten Sie die Taste 5 Sekunden lang gedrückt, um zwischen Lautstärkemodus und Lichtmodus umzuschalten / Houd 5 seconden ingedrukt om te schakelen tussen de volumemodus en de lichtmodus

LIGHT MODE / MODE RÉTROÉCLAIRAGE / MODO LUMINOSO / MODALITÀ LUMINOSA / LIGHT-MODUS / LICHTMODUS

(push): Switch light effects (17 kinds) / Effets lumineux (17 sortes) / Cambiar los efectos de luz (17 tipos) / Cambia gli effetti luminosi (17 tipi) / Lichteffekte umschalten (17 Arten) / Lichteffecten wisselen (17 soorten)

Adjusting the Backlight Brightness / Réglage de la luminosité du rétroéclairage / Ajustar el brillo de la retroiluminación / Regolazione della luminosità della retroilluminazione / Einstellen der Helligkeit der Hintergrundbeleuchtung / De helderheid van de achtergrondverlichting aanpassen

SOUND MODE / MODE AUDIO / MODO DE SONIDO / MODALITÀ AUDIO / TONMODUS / GELUIDSMODUS

(push): Mute On/Off / Activer/désactiver le mode silencieux / Silenciar/Desactivar el silencio / Attiva/Disattiva audio / Stummschaltung ein/aus / Geluid aan/uit

Adjusting volume / Réglage du volume / Ajustar el volumen / Regolazione del volume / Lautstärke einstellen / Het volume aanpassen

TECHNICAL SPECIFICATIONS SPÉCIFICATIONS ESPECIFICACIONES TÉCNICAS SPECIFICHE TECNICHE SPEZIFIKATIONEN SPECIFICATIES

Keyboard Type / Type de clavier / Tipo de teclado / Tipo di tastiera / Art der Tastatur / Type toetsenbord	Mechanical / Mécanique / Mecánica / meccanica / Mechanik / Werktuigbouwkunde
Activation force / Force d'activation / Fuerza de activación / Forza di attivazione / Aktivierungskraft / Activeringskracht	Activation force: 60±10gf Activation distance:4.0±0.5mm
Anti Ghosting Keys / Touches anti-ghosting / Teclas antifantasma / Chiavi anti-ghosting / Anti-Ghosting-Tasten / Anti-ghosting sleutels	26
Backlight / Rétroéclairage / Illumination / Retroiluminazione / Hintergrundbeleuchtung / Achtergrondverlichting	Rainbow
Multimedia shortcuts (Raccourcis multimédia / Atajos multimedia / Collegamenti multimediali / Multimedia-Verknüpfungen / Multimedia snelkoppelingen	12
Cable length / Longueur de câble / Longitud del cable / Lunghezza del cavo / Kabellänge / Kabellengte	1,5 m
Compatibility / Compatibilité / Compatibilidad / Compatibilità /Kompatibilität / Compatibiliteit	PC (Windows), macOS, PlayStation
Dimensions / Dimensions / Dimensiones / Dimensioni / Abmessungen / Afmetingen	428 x 119 x 36 mm
Weight / Poids / Peso / Peso / Gewicht / Gewicht	750g±10g (exclude the wrist weight) 895g±10g (include the wrist weight)
Connector / Connecteur / Conector / Connettore / Verbinder / Aansluiting	USB-A